

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

Copyright© 2005 by Big Bike Parts, Inc.
No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

VALKYRIE RADIATOR
ACCENT
PART NO. 1-307

FOR HONDA
VALKYRIE

ITEMS REQUIRED: #2 PHILLIPS SCREWDRIVER

1. USING THE PHILLIPS SCREWDRIVER, REMOVE THE FOUR SCREWS THAT HOLD THE OEM RADIATOR SCREEN ON, BEING CAREFUL NOT TO LOSE THE FOUR "J-NUTS"
2. SLIP ONE OF THE PLASTIC SHOW CAP BASES ON TO EACH OF THE NEW SCREWS PROVIDED AND MOUNT THE NEW CHROME RADIATOR ACCENT IN PLACE USING THE FOUR "J-NUTS".

NOTE: THERE IS ONLY ONE WAY TO POSITION THE ACCENT TO FIT, ONE OF THE MOUNTING HOLES IS 1" AWAY FROM THE EDGE, THIS IS THE BOTTOM LEFT FACING THE RADIATOR.

3. SNAP THE CHROME SHOW CAPS ONTO EACH SCREW.