

Revised 7/25/2017

TOOLS NEEDED: 8MM COMBINATION WRENCH
5MM ALLEN WRENCH
PHILLIPS SCREWDRIVER
DRILL
1/4" DRILL BIT
CONTACT CLEANER

INSTALLATION:

1. REMOVE THE 8MM BOLTS FROM THE HOSE CLAMP THAT HOLDS BRAKE LINE TO THE FRONT FENDER (BOTH SIDES).
2. REMOVE THE TWO (2) 5MM ALLEN BOLTS FROM THE LOWER FORK FENDER SUPPORTS (BOTH SIDES).
NOTE: FENDER WILL BE LOOSE, BE CAREFUL NOT TO SCRATCH IT WHILE REMOVING.
3. ATTACH THE RUBBER GASKETS TO THE INSIDE OF THE FRONT FENDER EXTENSION IN THE AREAS SHOWN. FIG. #1. BEFORE ATTACHING, THOROUGHLY CLEAN THE SURFACE WITH A CONTACT CLEANER.
4. POSITION THE FRONT FENDER EXTENSION ON THE FRONT FENDER 3/4" BEYOND THE EDGE (FIG #2) AND MARK THE FENDER ONLY AT EACH OF THE TWO INNER HOLES IN THE EXTENSION AS SHOWN. FIG #3.
5. REMOVE THE EXTENSION AND LIGHTLY CENTER PUNCH THE TWO INNER MARKS. USING A DRILL AND 1/4" DRILL BIT, DRILL A 1/4" HOLE THROUGH EACH CENTER PUNCHED MARK. FIG. #3
6. POSITION THE EXTENSION ON THE FRONT FENDER AGAIN AND TEMPORARILY INSTALL WITH TWO 5 X 9.5MM SCREWS AND 5MM FLANGE NUTS (INCLUDED) FIG #4. MARK THE FRONT FENDER AT EACH OF THE REMAINING TWO OUTER HOLES IN THE EXTENSION THEN REMOVE THE EXTENSION FROM THE FRONT FENDER. LIGHTLY CENTER PUNCH THE MARKS. FIG. #5.
7. USING A DRILL AND 1/4" DRILL BIT, DRILL A 1/4" HOLE THROUGH EACH CENTER PUNCHED MARK. FIG #6.
8. INSTALL THE FRONT FENDER EXTENSION.
9. REINSTALL THE FRONT FENDER IN THE REVERSE ORDER OF REMOVAL.

