

REVISED 5-18-12

TOOLS NEEDED: PHILLIPS SCREWDRIVER

NOTE: A DUAL LOAD EQUALIZER BBP PART # 13-304A OR LED FLASHER RELAY BBP PART # 13-306 IS REQUIRED FOR EACH BIKE TO RETURN TO TURN SIGNAL TO STOCK FLASH RATE

INSTALLATION:

1. REMOVE THE PHILLIPS SCREW ON BOTTOM OF HOUSING AND PULL LENS OFF HOUSING.
2. TAKE OFF THE METAL TINNERMAN CLIP THAT IS ON OLD LENS AND PLACE ON NEW LENS.
3. REMOVE THE OLD BULB FROM HOUSING.
4. REMOVE METAL SHIELD AT TOP INSIDE OF HOUSING.
5. PLUG THE LED CIRCUIT BOARD INTO BULB SOCKET AND PLACE LED CIRCUIT BOARD INTO LIGHT HOUSING WHERE SHIELD WAS REMOVED.
6. INSTALL NEW CLEAR LENS INTO HOUSING AND REUSE SCREW REMOVED IN STEP 1.

NOTE: IF BIKE HAS ONE TURN SIGNAL INDICATOR LIGHT FOR BOTH LEFT AND RIGHT, WILL NEED BBP PART # 13-308