

# **BIG BIKE PARTS®**

Copyright© 2006 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

## **INSTALLATION INSTRUCTIONS**

**LED T.S. CONVERSION KIT  
PART # 10-1705**

**FITS: KAWASAKI  
VN2000, VN1600 CLASSIC**

**TOOLS NEEDED: PHILLIPS SCREWDRIVER**

**NOTE: A DUAL LOAD EQUALIZER BBP PART # 13-304 IS REQUIRED FOR EACH KIT TO RETURN TO TURN SIGNAL TO STOCK FLASH RATE**

**INSTALLATION:**

1. REMOVE THE PHILLIPS SCREW ON BOTTOM OF HOUSING AND PULL LENS OFF HOUSING.
2. TAKE OFF THE METAL TINNEMAN CLIP THAT IS ON OLD LENS AND PLACE ON NEW LENS.
3. REMOVE THE OLD BULB FROM HOUSING.
4. REMOVE METAL SHIELD AT TOP INSIDE OF HOUSING.
5. PLUG THE LED CIRCUIT BOARD INTO BULB SOCKET AND PLACE LED CIRCUIT BOARD INTO LIGHT HOUSING WHERE SHIELD WAS REMOVED.
6. INSTALL NEW CLEAR LENS INTO HOUSING AND REUSE SCREW REMOVED IN STEP 1.

**NOTE: IF BIKE HAS ONE TURN SIGNAL INDICATOR LIGHT FOR BOTH LEFT AND RIGHT, WILL NEED BBP PART # 13-308**