

## BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

## INSTALLATION INSTRUCTIONS

Passenger Audio Controller  
Part No. 13-205

Fits: GL1500/6

TOOLS NEEDED: 6MM ALLEN WRENCH OR 13MM SOCKET WRENCH

### INSTALLATION:

1. REMOVE THE SEAT BY UN-BOLTING THE FOUR BOLTS LOCATED IN THE PASSENGER HANDLES. IF YOU HAVE A BACKREST, USE THE 13MM SOCKET WRENCH. IF YOU DO NOT HAVE A BACKREST, USE THE 6MM ALLEN WRENCH.
2. WITH THE SEAT REMOVED, LOCATE THE 6-PIN PLUG WHERE THE OEM WIRE HARNESS FOR THE PASSENGER HEADSET IS PLUGGED IN. FOLLOW THE CORD UNTIL YOU FIND IT AND UNPLUG THE OEM WIRE HARNESS.
3. WITH THE CORD REMOVED, TAKE THE NEW 13-205 AND TAKE THE 6-PIN MALE PLUG AND PLUG IT INTO THE 6-PIN FEMALE PLUG ON THE BIKE.
4. NEXT TO THESE PLUGS SHOULD BE ANOTHER 6-PIN MALE PLUG. TAKE THE 6-PIN FEMALE PLUG FROM THE 13-205 WITH ONLY TWO WIRES ATTACHED TO IT, PLUG IT INTO THE 6-PIN MALE PLUG ON THE BIKE.
5. RUN THE CABLE SO THAT THE CONTROL REACHES THE CORD HOLDER ON THE TRUNK.
6. RE-INSTALL THE SEAT THE SAME WAY IT WAS REMOVED.
7. CONTROL BOX CAN BE ATTACHED WITH THE VELCRO WHEREVER PASSENGER DESIRES. SUGGESTED LOCATION IS ON THE LEFT PASSENGER HANDLE.

## BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

## INSTALLATION INSTRUCTIONS

Passenger Audio Controller  
Part No. 13-205

Fits: GL1500/6

TOOLS NEEDED: 6MM ALLEN WRENCH OR 13MM SOCKET WRENCH

### INSTALLATION:

1. REMOVE THE SEAT BY UN-BOLTING THE FOUR BOLTS LOCATED IN THE PASSENGER HANDLES. IF YOU HAVE A BACKREST, USE THE 13MM SOCKET WRENCH. IF YOU DO NOT HAVE A BACKREST, USE THE 6MM ALLEN WRENCH.
2. WITH THE SEAT REMOVED, LOCATE THE 6-PIN PLUG WHERE THE OEM WIRE HARNESS FOR THE PASSENGER HEADSET IS PLUGGED IN. FOLLOW THE CORD UNTIL YOU FIND IT AND UNPLUG THE OEM WIRE HARNESS.
3. WITH THE CORD REMOVED, TAKE THE NEW 13-205 AND TAKE THE 6-PIN MALE PLUG AND PLUG IT INTO THE 6-PIN FEMALE PLUG ON THE BIKE.
4. NEXT TO THESE PLUGS SHOULD BE ANOTHER 6-PIN MALE PLUG. TAKE THE 6-PIN FEMALE PLUG FROM THE 13-205 WITH ONLY TWO WIRES ATTACHED TO IT, PLUG IT INTO THE 6-PIN MALE PLUG ON THE BIKE.
5. RUN THE CABLE SO THAT THE CONTROL REACHES THE CORD HOLDER ON THE TRUNK.
6. RE-INSTALL THE SEAT THE SAME WAY IT WAS REMOVED.
7. CONTROL BOX CAN BE ATTACHED WITH THE VELCRO WHEREVER PASSENGER DESIRES. SUGGESTED LOCATION IS ON THE LEFT PASSENGER HANDLE.