

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 2-410

CUBBYHOLDS – 1500™  
FOR HONDA GL1500/6 GOLDWING

1/18/2011

ITEMS REQUIRED: 1 CLEAN SOFT CLOTH 1 SOCKET WRENCH OR EQUIVALENT 8MM SIZE

## INSTALLATION:

1. CLEAN THE CUBBYHOLDS – 1500™ BEFORE INSTALLING.
2. REMOVE THE 8MM ACORN NUTS ON THE VERTICAL SURFACE OF THE LOWER TRUNK SIDES.
3. INSERT CUBBYHOLDS – 1500™ IN APPROPRIATE SIDES BY ANGLING THE LOWER REAR INTO POSITION FIRST, AND THEN SLIDE OVER THE EXPOSED BOLT.
4. REINSTALL THE ACORN NUTS IN PLACE SNUGGLY. DO NOT OVER TIGHTEN. TIGHTEN FIRMLY TO APPROXIMATELY 3 FOOT POUNDS.

GOLDWING & GL ARE TRADEMARKS OF HONDA.

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 2-410

CUBBYHOLDS – 1500™  
FOR HONDA GL1500/6 GOLDWING

1/18/2011

ITEMS REQUIRED: 1 CLEAN SOFT CLOTH 1 SOCKET WRENCH OR EQUIVALENT 8MM SIZE

## INSTALLATION:

1. CLEAN THE CUBBYHOLDS – 1500™ BEFORE INSTALLING.
2. REMOVE THE 8MM ACORN NUTS ON THE VERTICAL SURFACE OF THE LOWER TRUNK SIDES.
3. INSERT CUBBYHOLDS – 1500™ IN APPROPRIATE SIDES BY ANGLING THE LOWER REAR INTO POSITION FIRST, AND THEN SLIDE OVER THE EXPOSED BOLT.
4. REINSTALL THE ACORN NUTS IN PLACE SNUGGLY. DO NOT OVER TIGHTEN. TIGHTEN FIRMLY TO APPROXIMATELY 3 FOOT POUNDS.

GOLDWING & GL ARE TRADEMARKS OF HONDA.

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 2-410

CUBBYHOLDS – 1500™  
FOR HONDA GL1500/6 GOLDWING

1/18/2011

ITEMS REQUIRED: 1 CLEAN SOFT CLOTH 1 SOCKET WRENCH OR EQUIVALENT 8MM SIZE

## INSTALLATION:

1. CLEAN THE CUBBYHOLDS – 1500™ BEFORE INSTALLING.
2. REMOVE THE 8MM ACORN NUTS ON THE VERTICAL SURFACE OF THE LOWER TRUNK SIDES.
3. INSERT CUBBYHOLDS – 1500™ IN APPROPRIATE SIDES BY ANGLING THE LOWER REAR INTO POSITION FIRST, AND THEN SLIDE OVER THE EXPOSED BOLT.
4. REINSTALL THE ACORN NUTS IN PLACE SNUGGLY. DO NOT OVER TIGHTEN. TIGHTEN FIRMLY TO APPROXIMATELY 3 FOOT POUNDS.

GOLDWING & GL ARE TRADEMARKS OF HONDA.