

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

TOUR LIFT HANDLE
NO. 2-420

FOR 1988-95 GL1500/6
AND UNIVERSAL APPLICATIONS

Copyright© 1995 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

ITEMS REQUIRED: #2 PHILLIPS SCREWDRIVER, RULER, 1/4" DRILL BIT AND DRILL CENTER PUNCH, MASKING TAPE, HAMMER, PEN

INSTALLATION:

1. SET BIKE ON ITS CENTER STAND.
2. POSITION THE TOUR LIFT HANDLE SQUARELY ON THE TRUNK IN THE APPROXIMATE MOUNTING LOCATION AND PLACE MASKING TAPE UNDER EACH MOUNTING FOOT AREA.
3. USING THE RULER, CENTER THE HANDLE EQUALLY FROM LEFT TO RIGHT, KEEPING THE BOTTOM FEET 2" ABOVE THE TRUNK LID LIP. ONCE CENTERED, DRAW A CIRCLE ON EACH PIECE OF MASKING TAPE AROUND EACH MOUNTING FOOT.
4. REMOVE LIFT HANDLE AND VERIFY ALL YOUR MARKINGS ARE PROPERLY CENTERED AND POSITIONED, THEN USING THE CENTER PUNCH MARK EACH HOLE TO BE DRILLED.
5. ONCE AGAIN CONFIRM POSITIONING AND THEN DRILL A 1/4" HOLE THROUGH EACH OF THE 4 MOUNTING LOCATIONS.
6. REMOVE ALL TAPE AND INSTALL THE TOUR LIFT HANDLE USING THE 1/4" X 20 SCREWS, WASHERS AND RUBBER WASHER PROVIDED.