

Revised 7/25/2017

ITEMS REQUIRED: FLAT BLADE SCREWDRIVER #2 PHILLIPS SCREWDRIVER 8MM WRENCH
(A NEEDLE NOSE PLIERS MAY BE HELPFUL)

INSTALLATION:

1. REMOVE FAIRING FRONT COVER BY PULLING OUTWARD (1A) TO DISENGAGE BOSSES FROM FAIRING PANEL COVERS (2A).
2. USING A FLAT BLADE SCREWDRIVER, PRY OFF THE L/R BLACK PLASTIC UPPER SIDE TRIM PIECES. (2B) **NOTE: EACH SIDE HAS ONE LARGE AND ONE SMALL TRIM PIECE TO BE REMOVED.** REMOVE THE THREE PHILLIPS HEAD SCREWS (2F) FROM THE L/R LOWER FAIRING PANEL COVERS (2A).
3. USING A FLAT BLADE SCREWDRIVER, PRY OFF THE SCREW COVER (2C) FROM L/R LOWER FAIRING CORNER MOLDING TRIM. (2D) REMOVE THE PHILLIPS SCREW (2E) FROM THE L/R LOWER FAIRING CORNER MOLDING TRIM PIECES (2D).
4. USING AN 8MM WRENCH, REMOVE THE TWO ACORN NUTS (3A) AND THE OEM RADIATOR GRILLE (3B) AND THE FRAME (3C).
5. WITH OEM RADIATOR GRILLE AND SCREEN REMOVED, PLACE THE NEW TUBULAR RADIATOR GRILLE CENTERED OVER STOCK SCREEN.
6. USING THE PHILLIPS SCREWS (4A), FASTENING CLIPS (4C), AND MOUNTING BRACKETS (4C) INCLUDED, ATTACH THE NEW TUBULAR RADIATOR GRILLE TO THE SCREEN AND TIGHTEN MOUNTING HARDWARE SECURELY, BUT DO NOT OVER TIGHTEN. THE NEEDLE NOSE PLIERS MAY COME IN HANDY HERE TO DROP THE PHILLIPS SCREWS INTO PLACE.
7. REPLACE THE REMOVED ITEMS BY REVERSING STEPS 1 THROUGH 4.

