

# **BIG BIKE PARTS<sup>®</sup> INSTALLATION INSTRUCTIONS**

NO. 2-489

UPPER AIR VENT ACCENT  
FOR 1988-1999 GOLD WING

Copyright© 1998 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

TOOLS REQUIRED: SCREWDRIVER

INSTALLATION:

1. TO REMOVE EXISTING (OEM) AIR VENT, USE A SCREWDRIVER TO PRY BEHIND THE EDGES OF THE VENT.
2. INSTALL NEW VENTS BY PUSHING THEM INTO PLACE UNTIL FLUSH WITH PANEL.