

06/13/07

TOOLS NEEDED: PHILLIPS SCREWDRIVER 1/8" ALLEN WRENCH 3/8" WRENCH DRILL 3/16" DRILL BIT

1. REMOVE THE OEM RUBBER CORD CLIPS FROM THE BIKE.
2. PICK A SPOT FOR THE NEW EASY-CLIP CORD HOLDER (A). MAKE SURE THE AREA YOU ARE GOING TO INSTALL THE NEW EASY-CLIP CORD HOLDER (A) ON IS AS FLAT OF A SURFACE AS POSSIBLE.
3. WHEN YOU HAVE SELECTED THE PROPER PLACEMENT, CLEAN THE SURFACE WITH A SOFT CLOTH AND RUBBING ALCOHOL.
4. MAKE SURE THE EASY-CLIP CORD HOLDER (A) WILL BE MOUNTED SO THAT THE OEM HEADSET PLUG (B) CLIPS TO IT PROPERLY. FOR A PERMANENT INSTALLATION USE A 3/16" DRILL BIT TO MAKE THE PROPER SIZE HOLES FOR THE MACHINE SCREWS THEN PEEL THE BACKING OFF THE TAPE (C) ON YOUR EASY-CLIP CORD HOLDER (A) AND PRESS FIRMLY INTO PLACE. THEN FASTEN THE EASY-CLIP CORD HOLDER (A) TO THE BIKE USING THE MACHINE SCREWS (D), WASHERS (E), AND NUTS (F) PROVIDED. FOR THE REAR OF THE BIKE THE EASY-CLIP CORD HOLDER (A) MUST BE MOUNTED AS FAR AWAY FROM THE SEAT AS POSSIBLE TO ALLOW FOR EASY PLUG ACCESS.

