

BIG BIKE PARTS®

Copyright© 2004 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTUCTIONS

REPLACEMENT FOR HONDA
FLOORBOARDS VTX 1300 RETRO
PART NO. 21-554 VTX 1800 RETRO

TOOLS NEEDED: NEEDLE NOSE PLIERS

1. USING A NEEDLE NOSE PLIERS, REMOVE THE CLIP ON THE PIN HOLDING THE OEM BOARD ON.
2. TAKE OUT THE PIN CAREFULLY NOTING HOW THE SPRING FITS IN.
3. INSTALL THE NEW BOARD RE-USING THE SPRING, PIN AND CLIP.

BIG BIKE PARTS®

Copyright© 2004 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTUCTIONS

REPLACEMENT FOR HONDA
FLOORBOARDS VTX 1300 RETRO
PART NO. 21-554 VTX 1800 RETRO

TOOLS NEEDED: NEEDLE NOSE PLIERS

1. USING A NEEDLE NOSE PLIERS, REMOVE THE CLIP ON THE PIN HOLDING THE OEM BOARD ON.
2. TAKE OUT THE PIN CAREFULLY NOTING HOW THE SPRING FITS IN.
3. INSTALL THE NEW BOARD RE-USING THE SPRING, PIN AND CLIP.

BIG BIKE PARTS®

Copyright© 2004 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTUCTIONS

REPLACEMENT FOR HONDA
FLOORBOARDS VTX 1300 RETRO
PART NO. 21-554 VTX 1800 RETRO

TOOLS NEEDED: NEEDLE NOSE PLIERS

1. USING A NEEDLE NOSE PLIERS, REMOVE THE CLIP ON THE PIN HOLDING THE OEM BOARD ON.
2. TAKE OUT THE PIN CAREFULLY NOTING HOW THE SPRING FITS IN.
3. INSTALL THE NEW BOARD RE-USING THE SPRING, PIN AND CLIP.

BIG BIKE PARTS®

Copyright© 2004 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTUCTIONS

REPLACEMENT FOR HONDA
FLOORBOARDS VTX 1300 RETRO
PART NO. 21-554 VTX 1800 RETRO

TOOLS NEEDED: NEEDLE NOSE PLIERS

1. USING A NEEDLE NOSE PLIERS, REMOVE THE CLIP ON THE PIN HOLDING THE OEM BOARD ON.
2. TAKE OUT THE PIN CAREFULLY NOTING HOW THE SPRING FITS IN.
3. INSTALL THE NEW BOARD RE-USING THE SPRING, PIN AND CLIP.

BIG BIKE PARTS®

Copyright© 2004 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTUCTIONS

REPLACEMENT FOR HONDA
FLOORBOARDS VTX 1300 RETRO
PART NO. 21-554 VTX 1800 RETRO

TOOLS NEEDED: NEEDLE NOSE PLIERS

1. USING A NEEDLE NOSE PLIERS, REMOVE THE CLIP ON THE PIN HOLDING THE OEM BOARD ON.
2. TAKE OUT THE PIN CAREFULLY NOTING HOW THE SPRING FITS IN.
3. INSTALL THE NEW BOARD RE-USING THE SPRING, PIN AND CLIP.

BIG BIKE PARTS®

Copyright© 2004 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTUCTIONS

REPLACEMENT FOR HONDA
FLOORBOARDS VTX 1300 RETRO
PART NO. 21-554 VTX 1800 RETRO

TOOLS NEEDED: NEEDLE NOSE PLIERS

1. USING A NEEDLE NOSE PLIERS, REMOVE THE CLIP ON THE PIN HOLDING THE OEM BOARD ON.
2. TAKE OUT THE PIN CAREFULLY NOTING HOW THE SPRING FITS IN.
3. INSTALL THE NEW BOARD RE-USING THE SPRING, PIN AND CLIP.