

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2004 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

CHROME SWITCH  
BOX HOUSING-  
BRAKE SIDE  
PART NO. 51-333B

FITS MOST  
HONDA  
CRUISERS

ITEMS REQUIRED: #2 PHILLIPS SCREWDRIVER, 10MM WRENCH, FLAT SCREW DRIVER

NOTE: WE RECOMMEND PROFESSIONAL INSTALLATION BY A DEALER

## INSTALLATION:

1. ON THE RIGHT SIDE, REMOVE THE 10 MM NUT ON THE BRAKE LEVER MOUNT. THEN REMOVE THE MOUNTING SCREW & THE LEVER – THIS ALLOWS ROOM TO WORK W/CABLES & WIRES.
2. REMOVE (2) PHILLIPS HEAD SCREWS FROM BOTTOM SIDE OF SWITCH BOX. THIS ALLOWS THE SWITCH BOX TO BECOME SPLIT, TOP AND BOTTOM.
3. UNHOOK THE THROTTLE CABLES & REMOVE THE TWIST GRIP.
4. ON THE BOTTOM HALF OF THE SWITCH BOX REMOVE THE PHILLIPS SCREW THAT HOLDS THE BRASS WIRE CLAMP & REMOVE THE CLAMP.
5. REMOVE THE PHILLIPS SCREW THAT HOLDS THE STARTER SWITCH IN PLACE & REMOVE THE SWITCH.
6. REVERSE STEPS 4 & 5 USING THE NEW BOTTOM HALF OF THE HOUSING.
7. ON THE TOP HALF OF THE SWITCH HOUSING, REMOVE THE BRASS KEEPER & KILL SWITCH BY REMOVING (2) PHILLIPS SCREWS.
8. NEXT THE THROTTLE CABLE CAN BE REMOVED FROM THE HOUSING & THE SWITCH HOUSING CAN BE SET ASIDE.
9. REINSTALL CABLES INTO THE NEW HOUSING & THEN REINSTALL THE KILL SWITCH BY REVERSING STEP (7).
10. REINSTALL THE THROTTLE TWIST GRIP AND ATTACH THE THROTTLE CABLES.
11. REVERSE STEPS 1 & 2.
12. READJUST THE THROTTLE CABLES.
13. CHECK ALL SWITCHES MAKING SURE THEY ARE WORKING PROPERLY.