

BIG BIKE PARTS® **INSTALLATION INSTRUCTIONS**

PART NO. 51-333C

**CHROME SWITCH BOX
HOUSING- CLUTCH SIDE
FITS MOST HONDA CRUISERS**

Copyright© 2000 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

ITEMS REQUIRED: #2 PHILLIPS SCREWDRIVER, 10MM WRENCH, FLAT SCREW DRIVER

NOTE: WE RECOMMEND PROFESSIONAL INSTALLATION BY A DEALER.

INSTALLATION:

1. ON THE LEFT SIDE OF THE HANDLE BARS, REMOVE THE (2) PHILLIPS HEAD SCREWS ON THE BOTTOM SIDE OF THE SWITCH BOX. THIS ALLOWS THE SWITCH BOX TO BE OPENED INTO TWO PIECES (TOP & BOTTOM)
2. IF A CHOKE LEVER IS USED ON THIS SWITCH BOX, (SOME MODELS) RELEASE THE CABLE END FROM THE LEVER & REMOVE THE CHOKE CABLE FROM THE SWITCH BOX USING A 11MM WRENCH.
3. ON THE INSIDE OF THE BOTTOM HALF OF THE SWITCH BOX REMOVE THE PHILLIPS HEAD SCREW THAT HOLDS THE WIRE CLAMP IN PLACE & REMOVE THE WIRE CLAMP.
4. REMOVE THE (2) SCREWS & TURN SIGNAL SWITCH ARM.
5. REMOVE THE HORN BUTTON SCREW & REMOVE THE HORN BUTTON.
6. USING THE NEW CHROME BOTTOM HALF OF THE SWITCH BOX, REINSTALL THE HORN BUTTON, THE TURN SIGNAL SWITCH ARM & THE CHOKE CABLE (IF USED) BY REVERSING STEPS 2 THRU 5.
7. ON THE INSIDE OF THE TOP HALF OF THE SWITCH BOX, REMOVE THE WIRE CLAMP BY REMOVING THE PHILLIPS SCREW.
8. REMOVE THE (2) PHILLIPS SCREWS FROM THE HEADLIGHT HI / LOW SWITCH & REMOVE THE SWITCH.
9. REINSTALL INTO NEW CHROME SWITCH BOX BY REVERSING STEPS 7 & 8.
10. NEXT REINSTALL BOTH TOP & BOTTOM HALVES BY REVERSING STEPS 1 & 2.
11. CHECK ALL SWITCHES, BUTTONS & LEVERS FOR CORRECT FUNCTIONS.