

BIG BIKE PARTS®

Copyright© 2008 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTRUCTIONS PART NO. 52-605, 52-605LM, 52-705LM

GL1500/6, GL1800, VALKYRIE,
VT1100, VT600, VT750 ACE,
SPIRIT, ROAD STAR, VENTURE,
ROYAL STAR, VTX

Revised 1/30/2009

ITEMS REQUIRED: #2 PHILIPPS SCREWDRIVER

CAUTION: BE SURE TO COVER THE TANK AND FENDER WITH TOWELS. BRAKE FLUID WILL DESTROY THE PAINT.

INSTALLATION:

1. USING PHILLIPS SCREWDRIVER, REMOVE EXISTING MASTER CYLINDER COVER (1D) ON BIKE.
2. PLACE SWITCH BLOCK (1B) ON TOP OF MASTER CYLINDER (1A). PLACE GASKET (1C) OVER TOP OF SWITCH BLOCK (1B).
3. USING NEW LONGER SCREWS (1E) INSTALL MASTER CYLINDER COVER (1D) ON TOP OF SWITCH BLOCK (1B).
4. THE RED WIRE IS TO BE CONNECTED TO YOUR ACCESSORY TERMINAL ON BIKE. THE OTHER WIRES ARE TO CONNECT THE POSITIVE WIRE FROM YOUR ACCESSORIES.
5. CHECK TO MAKE SURE ACCESSORIES WORK AND THAT MASTER CYLINDER DOES NOT LEAK BRAKE FLUID.

