

**BIG BIKE PARTS®** INSTALLATION INSTRUCTIONS  
CHROME ABS FITS GL1800 GOLDWING  
LOWER VENTS  
PART NO. 52-642

Copyright© 2002 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

TOOLS REQUIRED: FLAT BLADE SCREWDRIVER

INSTALLATION:

1. CAREFULLY PRY ON THE SIDES OF THE OLD AIR VENT TO SNAP IT OUT.
2. INSTALL THE NEW AIR VENTS BY SNAPPING IT INTO THE OPENING.