

BIG BIKE PARTS® INSTALLATION INSTRUCTION

Copyright© 2009 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written permission
of Big Bike Parts, Inc.©

CHROME FRONT FENDER EXT.

PART NO. 52-601A

PART NO. 52-655

HONDA GL1800 GOLD WING

NOT AIRBAG MODEL

Revised 7/27/09

ITEMS REQUIRED: 5MM ALLEN WRENCH
DRILL
3/8" DRILL BIT
WOODEN BLOCK

INSTALLATION:

NOTE: BEFORE YOU DRILL THE HOLE IN THE FENDER, MAKE SURE THAT THE FENDER EXTENSION IS CENTERED PROPERLY ON THE FENDER AND THAT THE DRILLED HOLES ARE CENTERED WITH THE HOLES IN THE FENDER EXTENSION. WE RECOMMEND USING LOC-TITE ON THE SCREWS. DO NOT OVER TORQUE. IF THE SCREWS ARE TOO TIGHT IT MAY CAUSE THE FENDER TO CRACK.

1. MAKE SURE BIKE IS SECURE ON ITS CENTER STAND.
2. POSITION FRONT FENDER EXTENSION ON THE FRONT FENDER. MAKE SURE THE RIBS IN BACK OF EXTENSION TOUCH FENDER.
3. MARK THE TWO HOLES ON FENDER TO BE DRILLED. REMOVE FENDER EXTENSION.
4. WITH DRILL & 3/8" DRILL BIT, DRILL HOLES FOR EXTENSION; BE SURE TO PLACE WOODEN BLOCK BEHIND FENDER SO YOU DON'T PUNCTURE TIRE.
5. CLEAN THE FENDER WHERE THE EXTENSION WILL BE PLACED.
6. REMOVE ADHESIVE BACKING AND ATTACH THE FENDER EXTENSION IN PLACE.
7. PUT THE SPECIAL NUT THROUGH HOLE ON BACKSIDE OF FENDER, TIGHTEN WITH SCREWS.

