

INSTALLATION INSTRUCTIONS LOWER RAIN DEFLECTOR PART NO. 52-725 FITS HONDA GL1800 GOLD WING

Revised 2/16/09

TOOLS REQUIRED: 4MM ALLEN WRENCH
10MM WRENCH

1. ASSEMBLE THE TWO PLASTIC CLIPS (1A) TO THE PANEL (1B) USING M6 X 1.00 X 13MM LONG SCREW (1C), LOCKNUT (1D) AND PLASTIC WASHER (1E). DO NOT TIGHTEN DOWN.
2. SLIDE THE CLIPS ONTO THE LOWER CRASH BAR (1F). THE SIDE WITH THE ROUND CUT-OUT GOES AGAINST THE LOWER COWL.
3. DO THE SAME FOR THE OTHER SIDE.
4. TIGHTEN ALL SCREWS DOWN TIGHT.

