

BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big bike Parts, Inc. ®

INSTALLATION INSTRUCTIONS

CLEAR LENS SADDLEBAG

HONDA GL1800 GOLDWING 01-05

LIGHTS

PART NO. 52-735

TOOLS NEEDED: 8MM SOCKET AND RATCHET

INSTALLATION:

1. USING 8MM SOCKET REMOVE THE THREE ACORN NUTS ON THE INSIDE OF THE SADDLEBAG THAT ARE HOLDING THE LIGHT HOUSING IN.
2. REMOVE LIGHT HOUSING AND REMOVE THE LIGHT BULB SOCKETS BY TURNING THEM OUT.
3. REMOVE THE CLEAR BULBS AND REPLACE WITH THE NEW CLEAR AND AMBER BULBS PROVIDED (CLEAR GOES ON BOTTOM AND AMBER GOES ON TOP).
4. INSTALL LIGHT BULB SOCKETS INTO NEW LIGHT HOUSING.
5. INSTALL NEW LIGHT HOUSING INTO SADDLEBAG REUSING ACORN NUTS REMOVED IN STEP #1.