

BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big bike Parts, Inc. ®

INSTALLATION INSTRUCTIONS

CLEAR LED TRUNK LIGHTS

**HONDA GL1800 GOLDWING
2001-**

PART NO. 52-736L

ITEMS REQUIRED: 8MM SOCKET WRENCH OR NUT DRIVER.

1. OPEN THE TRUNK LID AND REMOVE THE 3 NUTS HOLDING EACH LIGHT. SAVE THE NUTS.
2. REMOVE THE LIGHTS FROM THE POCKET IN THE TRUNK AND REMOVE THE BLACK BULB SOCKETS BY TURNING THEM COUNTER CLOCKWISE. REMOVE ANY BULBS, AS THEY WILL NOT BE NEEDED.
3. WITH THE NEW LIGHT IN YOUR HAND, INSERT THE SMALL BLACK LED PLUG INTO THE BULB SOCKET. THE BLACK WIRE ON THE LED PLUG SHOULD ALIGN WITH THE GREEN WIRE ON THE BULB SOCKET. IT IS BEST TO HAVE THE KEY ON AT THIS TIME TO ENSURE THAT THE LED'S LIGHT UP WHEN THEY ARE PLUGGED IN. IF THEY DO NOT, REVERSE THE PLUG AND RE-INSERT IT INTO THE BULB SOCKET.
4. WITH BOTH LED PLUGS IN THE BULB SOCKETS, DISCONNECT THE OEM PLUG FROM THE BULB SOCKET SO THAT IT IS EASIER TO INSERT THE SOCKET INTO THE LIGHT HOUSING. COIL THE WIRE AS NECESSARY BY ROTATING THE BULB SOCKET. INSERT EACH BULB SOCKET INTO THE HOUSING BY ALIGNING THE SMALL TAB WITH THE SMALL HOLE AND ROTATE IT CLOCKWISE UNTIL THE CONNECTION FOR THE OEM PLUG IS FACING TOWARDS THE BOTTOM OF THE LIGHT.
5. INSERT OEM PLUGS INTO BULB SOCKETS.
6. INSERT THE LIGHTS INTO THE TRUNK AND ATTACH WITH THE NUTS THAT WERE REMOVED IN THE FIRST STEP.