

BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

INSTALLATION INSTRUCTIONS

CHROME TIMING

FITS: GL1800 2001-10

CHAIN COVER

ALL MODELS

PART # 52-739

Revised 2-19-10

TOOLS NEEDED: 17MM SOCKET AND WRENCH
RUBBING ALCOHOL

INSTALLATION:

1. REMOVE THE STOCK TIMING CHAIN COVER INSPECTION NUT USING 17MM SOCKET.
2. REMOVE THE RUBBER O-RING SEAL FROM BACK OF THE STOCK INSPECTION NUT AND PLACE SEAL ON NEW INSPECTION NUT.
3. INSTALL THE NEW INSPECTION NUT USING 17MM SOCKET. NOTE: NEW INSPECTION NUT WILL STICK OUT FURTHER THAN STOCK NUT DID TO BE FLUSH WITH COVER.
4. CLEAN THE ENTIRE SURFACE OF STOCK COVER WITH RUBBING ALCOHOL. REMOVE THE PROTECTIVE BACKING ON TAPE ON BACK OF COVER. ALIGN THE CENTER CUTOUT WITH THE INSPECTION NUT AND APPLY PART LOOSELY. ONCE IT IS CENTERED, PRESS AND HOLD FIRMLY FOR 30 SECONDS.