

Copyright© 2003 by Big Bike Parts, Inc.
No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

LED WINDSHIELD GARNISH
PART NO. 52-697A & 52-756

FITS HONDA
GL1800 GOLD WING

Revised 08-14-06

TOOLS REQUIRED: 10 MM WRENCH
RUBBING ALCOHOL

1. RELEASE THE HEIGHT ADJUSTMENT LEVER (1A) ON THE LEFT AND RIGHT SIDE.
2. PULL BACK THE RUBBER COVER (1B) OVER THE LEFT AND RIGHT MIRRORS.
3. USING 10MM WRENCH REMOVE THE BOLT (2A), WASHER (2B) AND RUBBER WASHER (2C) ON BOTH SIDES. BE CAREFUL NOT TO DROP ANY OF THE HARDWARE DOWN INSIDE THE FAIRING.

NOTE: THE MIRRORS CAN MOVE FORWARD TO HELP GAIN ACCESS TO BOLTS.

4. PULL THE WINDSHIELD GARNISH (2D) AT TOP CORNERS AND AT BOTTOM TO RELEASE BOSSES (2E) FROM GROMMETS (2F).
5. CLEAN THE AREA ABOVE CUTOUT IN GARNISH WITH RUBBING ALCOHOL.
6. INSTALL THE LED LIGHT STRIP TO THE GARNISH AT THE OPENING SO THE LIGHTS ARE POINTING OUT THROUGH THE OPENING. APPLY THE DOUBLE SIDED TAPE PROVIDED TO THE LED HOUSING (SEE FIGURE 3 FOR DETAILS).
7. RUN THE WIRES OVER TO THE SIDE BY MIRRORS AND PLUG THE 3 PIN CONNECTOR INTO THE BLACK 3 PIN CONNECTOR ON THE BIKE THAT RUNS THE MIRROR LIGHTS.
8. REINSTALL THE GARNISH IN REVERSE OF REMOVAL.

