

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

SADDLEBAG STAYS

FITS SABRE

PART NO. 53-115

VT1100 C2 00-05

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

TOOLS NEEDED: 5MM ALLEN WRENCH 12MM SOCKET
 14MM SOCKET

INSTALLATION:

NOTE: IT IS RECOMMENDED TO USE LOC-TITE ON ALL BOLTS.

1. USING 14MM SOCKET, REMOVE THE BOLT AT FRONT OF FENDER STRUT.
2. USING 12MM SOCKET, REMOVE BOLT AT REAR OF FENDER STRUT.
3. USING 10MM BOLT PROVIDED AT FRONT OF FENDER STRUT AND 8MM BOLT PROVIDED AT REAR OF FENDER STRUT. INSTALL THE SADDLEBAG STAY.
4. REPEAT STEPS 1 THROUGH 3 FOR OTHER SIDE.