

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

NECK COVERS VT1100

PART # 53-117

Copyright© 2006 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

TOOLS NEEDED: PHILLIPS HEAD SCREW DRIVER
8MM SOCKET WRENCH

NOTE: TO INSTALL THESE NECK COVERS, YOU WILL NEED A SECOND PERSON TO HELP HOLD THE TANK DURING INSTALLATION.

INSTALLATION:

1. USING THE 8MM SOCKET WRENCH, REMOVE THE BOLT AT THE FRONT OF THE GAS TANK HOLDING THE FRONT OF THE TANK DOWN.
2. HAVE A SECOND PERSON LIFT THE FRONT OF THE TANK UP. REMOVE THE TWO OEM PLASTIC SCREW RIVETS HOLDING EACH NECK COVER ON.
3. INSTALL THE NEW NECK COVERS BY USING THE OEM HARDWARE REMOVED IN STEP #2 IN THE REVERSE ORDER OF REMOVAL.
4. REINSTALL THE BOLT FOR THE FRONT OF THE GAS TANK REMOVED IN STEP #1, AND TIGHTEN TO MANUFACTURERS SPECIFICATIONS.