

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

SADDLEBAG STAYS
PART NO. 53-417

FITS HONDA
VT750 AERO

Copyright© 2004 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

TOOLS NEEDED: 5MM ALLEN WRENCH
14MM WRENCH

NOTE: WE RECOMMEND USING LOC-TITE ON ALL BOLTS.

INSTALLATION:

1. USING A 14MM WRENCH REMOVE THE TWO STRUT BOLTS (THE ONES AT THE FRONT OF THE STRUT) ON ONE SIDE ONLY. THESE BOLTS WILL NOT BE REUSED.
2. INSTALL THE SADDLEBAGS USING THE M10 X 1.25 X 65MM LONG BOLTS PROVIDED.
3. REPEAT STEPS 1 & 2 FOR THE OTHER SIDE.