

BIG BIKE PARTS®

Copyright© 2006 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

INSTALLATION INSTRUCTIONS

Rear Shock Bolt Covers

Part No. 55-115

Fits Honda VTX 1300

VTX 1800

TOOLS NEEDED: 2MM ALLEN WRENCH

INSTALLATION:

1. THERE ARE FOUR COVERS, 2 LARGE AND 2 SMALL. THE TWO LARGE COVERS ARE FOR THE TOP 2 REAR SHOCK BOLTS. THE 2 SMALL COVERS ARE FOR THE BOTTOM 2 SHOCK BOLTS. THERE IS A NOTCH IN ONE OF THE SMALL SHOCK BOLT COVERS. THIS NOTCHED COVER MUST GO ON THE BOTTOM LEFT SHOCK BOLT.
2. USING A 2MM ALLEN WRENCH, PLACE THE SHOCK BOLT COVER OVER THE SHOCK BOLT AND TIGHTEN THE 2 SET SCREWS ON EACH SIDE OF THE COVER.
3. REPEAT FOR ALL FOUR BOLTS.