

BIG BIKE PARTS®

Copyright© 2008 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

INSTALLATION INSTRUCTIONS

Part No. 55-144

Part No. 55-145

RADIATOR GRILLE

HONDA VTX1800

04/06/09

TOOLS NEEDED: 10MM WRENCH
5MM ALLEN WRENCH

INSTALLATION:

1. REMOVE RADIATOR GRILLE FRAME BY USING 5MM ALLEN WRENCH TO REMOVE ALL SOCKET BUTTON HEAD SCREWS; TWO ON TOP, TWO ON EACH SIDE, AND ONE ON BOTTOM. REMOVE RADIATOR GRILLE.
2. REMOVE RADIATOR GRILL LOWER SUPPORT BRACKET BY USING 10MM WRENCH TO REMOVE TWO HEX HEAD SCREWS.
3. REMOVE THREE HEX HEAD SCREWS THAT ATTACH RADIATOR TO FRAME BY USING 10MM WRENCH; ONE ON TOP AND TWO ON BOTTOM OF RADIATOR.
4. INSTALL THE ANTI-VIBRATION RUBBER ON BACK OF NEW RADIATOR GRILLE LINING UP CORRECTLY WITH THE BIKE. EACH ABOUT 1 INCH FROM THE EDGE AND A 1/2 INCH ABOVE THE MESH GRILLE INSERT.

IF INSTALLING NEW BBP RADIATOR GRILLE ON BIKE THAT HAS BBP HIGHWAY BARS SKIP TO STEP #6, IF NOT GO TO STEP #5.

5. INSTALL NEW BBP RADIATOR GRILLE USING SCREWS PROVIDED. USING 5MM ALLEN WRENCH INSTALL BOTTOM TWO SCREWS BUT DO NOT TIGHTEN, THEN USING 10MM WRENCH INSTALL TOP SCREW THEN TIGHTEN ALL THREE SCREWS.
6. INSTALL NEW BBP RADIATOR GRILLE OVER BBP HIGHWAY BARS BY USING SCREWS AND SPACERS PROVIDED. PLACE SPACERS BETWEEN RADIATOR GRILLE AND FRAME AND ALIGNING WITH TWO BOTTOM HOLES. USING 5MM ALLEN WRENCH INSTALL TWO BOTTOM SOCKET HEAD CAP SCREWS BUT DO NOT TIGHTEN, THEN USING 10MM WRENCH INSTALL TOP HEX HEAD SCREW, THEN TIGHTEN ALL THREE SCREWS.
7. ALSO, THE TWO HOLES ON EACH SIDE OF THE RADIATOR CAN BE USED FOR INSTALLING OUR LED REFLECTOR LIGHTS, IF YOU CHOOSE.