

# BIG BIKE PARTS®

Copyright© 2006 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

## INSTALLATION INSTRUCTIONS

FRONT FENDER RAIL VTX1300 RETRO

PART # 55-317

TOOLS NEEDED: 6MM WRENCH  
13MM WRENCH

### INSTALLATION:

1. REMOVE THE FOUR BOLTS HOLDING THE FRONT FENDER ON, ONE AT A TIME, USING THE 6MM ALLEN WRENCH, AND REPLACING THEM WITH THE NEW M8 X 1.25 BOLTS SUPPLIED. DO NOT TIGHTEN ALL THE WAY.
2. WITH THE FOUR LONGER BOLTS PARTIALLY STICKING OUT THE INSIDE OF THE FENDER, ABOUT ¼", SLIDE THE FENDER RAIL ONTO THE BOLTS STICKING OUT.
3. WITH THE FENDER RAIL IN PLACE, TIGHTEN DOWN THE FOUR M8 X 1.25 BOLTS USING THE 6MM ALLEN WRENCH.
4. INSTALL AND TIGHTEN THE FOUR M8 X 1.25 NYLOCK LOCK NUTS. TO MAKE SURE THAT THE BOLTS DON'T TURN PLACE, PUT THE ALLEN WRENCH IN THE BOLTS TO PREVENT THEM FROM MOVING WHILE TIGHTENING THE NUTS ON THE INSIDE OF THE FENDER.