

BIG BIKE PARTS

INSTALLATION INSTRUCTIONS

Copyright© 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc. ®

CELESTAR RADIATOR GRILLE
PART NO. 61-108

FITS YAMAHA
ROYAL STAR
VENTURE 1999-2009

Revised 6/19/09

TOOLS REQUIRED: 10MM WRENCH
 4MM ALLEN WRENCH

1. REMOVE THE LOWER FAIRING SHROUDS BY USING THE 4MM ALLEN WRENCH – TWO SCREWS ON THE FRONT & ONE SCREW ON THE BACK SIDE OF EACH SHROUD (RIGHT & LEFT SIDES).
2. USING A 10MM WRENCH, REMOVE THE TOP & LOWER BOLTS THAT HOLD THE AIR CLEANER BOX ONTO THE BRACKET (BOTH SIDES).
3. USING A 10MM WRENCH, REMOVE THE TOP BOLT THAT HOLDS THE AIR CLEANER BRACKET ONTO THE FRAME & LOOSEN THE BOTTOM BOLT ON BRACKET (BOTH SIDES).
4. USING A 10MM WRENCH REMOVE THE BOLT ON THE SIDE OF THE RADIATOR NEAR THE BOTTOM (BOTH SIDES).
5. INSTALL THE NEW GRILLE OVER THE RADIATOR WITH THE OPEN END DOWN. THE TOP MOUNTING TABS ARE NOW INSERTED BETWEEN THE AIR CLEANER BRACKET TOP MOUNT & THE FRAME, REPLACE THE BOLTS THAT WERE REMOVED. (NOTE: THE TABS MAY NEED TO BE BENT TO ALLOW THEM TO GO BETWEEN THE BRACKET & FRAME) **DO NOT** TIGHTEN YET!
6. LINE UP THE BOTTOM TABS WITH THE HOLES AT THE BOTTOM OF THE RADIATOR & RE-INSTALL THE BOLTS THAT WERE REMOVED & TIGHTEN THEM IN PLACE, USING THE 10MM WRENCH. **NOTE:** MAY NEED TO LIFT UP ON RADIATOR TO LINE UP HOLES.
7. GO BACK TO THE TOP TABS & TIGHTEN THEM USING THE 10MM WRENCH.
8. RE-INSTALL THE AIR CLEANERS & LOWER FAIRING SHROUDS BY REVERSING STEPS 1 THRU 4.