

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 61-113

CHROME SIDE COVERS

YAMAHA ROYAL STAR 1996 & NEWER

TOOLS NEEDED: PHILLIPS SCREWDRIVER                      5MM ALLEN WRENCH                      10MM WRENCH OR SOCKET  
SOCKET WRENCH AND AN EXTENSION FOR THE SOCKET WRENCH

## INSTALLATION:

1. REMOVE THE LEFT SIDE BY REMOVING THE TWO SCREWS AT THE TOP OF THE COVER AND THEN PULL THE SIDE COVER OUT OF THE TWO GROMMETS AT THE FRONT, IN THE MIDDLE SIDE COVER, HOLDING IT IN PLACE.
2. INSTALL THE FORWARD OEM BOLT TO THE NEW SIDE COVER WITH ONE OF THE M6 NUTS SUPPLIED.
3. REPEAT STEPS ONE AND TWO FOR THE RIGHT SIDE.
4. REMOVE THE TWO BOLTS, ONE ON EACH SIDE, ON THE BOTTOM CORNERS ON THE CENTER COVER BY USING THE 10 MM SOCKET AND EXTENSION TO REACH.
5. REMOVE THE DRIVER SEAT BY REMOVING THE TWO BOLTS, ONE ON EACH SIDE, LOCATED NEAR THE FRONT PART OF THE SEAT BY THE FRAME USING THE 5MM ALLEN WRENCH.
6. WITH THE SEAT REMOVED, REMOVE THE SCREW HOLDING THE TOP OF THE CENTERPIECE IN BY USING THE PHILLIPS HEAD SCREWDRIVER.
7. SLIDE THE CENTER PIECE OUT THRU THE LEFT HAND SIDE.
8. REMOVE THE GROMMETS, BUSHINGS, AND THE TWO NUTS AND BOLTS FROM THE OLD CENTERPIECE AND INSTALL ON THE NEW CENTERPIECE.
9. REINSTALL THE CENTERPIECE IN REVERSE ORDER OF REMOVAL.
10. REINSTALL THE DRIVER SEAT. REMOVE THE RUBBER GROMMETS FROM THE TWO SIDE COVERS AND INSTALL THE NEW SIDE COVERS. WETTING THE RUBBER GROMMETS MAY AID IN INSTALLATION.
11. REINSTALL THE TWO NEW SIDE COVERS BY USING THE BOLT REMOVED PREVIOUSLY AND POP THE GROMMETS INTO THE CENTERPIECE.

