

# BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

# INSTALLATION INSTRUCTIONS

## CHROME SIDE COVERS

## YAMAHA ROAD STAR

### PART # 62-113

Revised 08/28/07

TOOLS NEEDED: PHILLIPS SCREWDRIVER  
10 MM SOCKET  
5MM ALLEN WRENCH

INSTALLATION:

1. USING 5MM ALLEN WRENCH, REMOVE SCREW FROM RIGHT SIDE COVER AND REMOVE RIGHT SIDE COVER.
2. USING 10MM SOCKET REMOVE BOLT HOLDING THE CENTER PIECE TO BIKE BEHIND THE ENGINE.
3. USING 5MM ALLEN WRENCH, REMOVE SCREW FROM LEFT SIDE COVER, AND REMOVE LEFT SIDE COVER.
4. USING PHILLIPS SCREWDRIVER, REMOVE THE CENTER PIECES FROM OLD SIDE COVERS AND INSTALL ON THE NEW CHROME SIDE COVERS USING NEW SCREWS AND NUTS PROVIDED.
5. INSTALL THE NEW CHROME SIDE COVERS ON BIKE IN THE REVERSE OF REMOVAL.