

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 62-115

CHROME INNER SIDE COVERS
YAMAHA ROAD STARS

09/11/07

TOOLS NEEDED: 5MM ALLEN WRENCH
FLAT BLADE SCREWDRIVER
10MM WRENCH

8MM SOCKET
NEEDLE NOSE PLIERS

PHILLIPS SCREWDRIVER
THREADLOCKER

NOTE: WE RECOMMEND USING THREADLOCKER ON ALL HARDWARE INSTALLED.

1. USING A 5MM ALLEN WRENCH, REMOVE THE SCREW AT THE REAR OF THE LEFT OUTER SIDE COVER AND REMOVE THE LEFT SIDE COVER ASSEMBLY BY PULLING OUT.
2. WITH THE 8MM SOCKET REMOVE THE HEX HEAD SCREW FROM THE RIGHT INNER SIDE COVER LOCATED UNDER THE SEAT. TO ACCESS THE SCREW YOU MUST COME FROM THE LEFT SIDE.
3. USING A 5MM ALLEN WRENCH, REMOVE THE SCREW AT THE REAR OF THE RIGHT OUTER SIDE COVER AND REMOVE THE SIDE COVER ASSEMBLY BY PULLING OUT.
4. REMOVE THE U-NUT FROM THE OEM RIGHT INNER SIDE COVER AND INSTALL IT ON THE NEW CHROME INNER SIDE COVER. THEN USING A FLAT BLADE SCREWDRIVER OR NEEDLE NOSE PLIERS REMOVE THE TINNERMANS NUT FROM THE NIPPLE ON THE OEM INNER RIGHT SIDE COVER. FINALLY, USING A PHILLIPS HEAD SCREWDRIVER REMOVE THE SCREW HOLDING THE OEM INNER AND OUTER SIDE COVERS TOGETHER ALLOWING THEM TO BE DETACHED FROM EACH OTHER.
5. PLACE THE 1.8MM THICK SPACER BETWEEN THE MOUNTING TABS ON THE NEW CHROME INNER RIGHT SIDE COVER AND THE OUTER RIGHT SIDE COVER BEING INSTALLED ON YOUR BIKE, PLACE A PROVIDED SCREW THROUGH THE MOUNTING HOLES AND SPACER, PLACE A NUT ON THE BACKSIDE AND TIGHTEN USING A PHILLIPS SCREWDRIVER AND A 10MM WRENCH. ALIGN THE OUTER CONTOURS OF THE COVERS WHILE TIGHTENING. PLACE THE TINNERMANS NUT ON THE NIPPLE AND PUSH TIGHT AGAINST THE TAB.
6. REMOVE THE TWO RUBBER GROMMETS FROM THE LEFT OEM INNER SIDE COVER AND INSTALL THEM INTO THE NEW CHROME INNER LEFT SIDE COVER.
7. PLACE ONE OF THE TWO 1.15MM THICK SPACERS BETWEEN EACH MOUNTING TAB ON THE NEW CHROME INNER LEFT SIDE COVER AND THE OUTER LEFT SIDE COVER BEING INSTALLED ON YOUR BIKE, PLACE A PROVIDED SCREW THROUGH EACH MOUNTING HOLE AND SPACER, PLACE A NUT ON THE BACKSIDE AND TIGHTEN USING A PHILLIPS SCREWDRIVER AND A 10MM WRENCH. ALIGN THE OUTER CONTOURS OF THE COVERS WHILE TIGHTENING.
8. INSTALL THE RIGHT SIDE COVER ASSEMBLY IN REVERSE ORDER OF STEPS 2 AND 3.
9. INSTALL THE LEFT SIDE COVER ASSEMBLY IN REVERSE ORDER OF STEP 1.

