

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

CHOKE KNOB COVER PART NO. 63-124 FITS MOST HONDA & YAMAHA CRUISER

Copyright© 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.©

Revise 07/23/07

ITEMS REQUIRED: 1.5MM WRENCH

1. PULL THE CHOKE KNOB (1A) OUT.
2. SLIDE THE INNER RING (1B) ONTO THE CHOKE LEVER ROD (1F).
3. SLIDE THE INNER RING (1B) UP AND AROUND THE FACTORY CHOKE KNOB (1A).
4. YOU WILL NEED TO PLACE ONE OF THE ROUND RUBBER DISCS (1C) ON THE FACTORY CHOKE KNOB (1A). SEE NOTE:

NOTE: DUE TO SIZE DIFFERENCE IN CHOKE KNOBS (1A), WE HAVE PROVIDED TWO ROUND RUBBER DISCS (1C) TO TAKE UP SPACE BETWEEN THE FACTORY CHOKE KNOB (1A) AND OUR CHOKE KNOB COVER (1D).

5. SLIDE OUR CHOKE KNOB COVER (1D) OVER THE INNER RING (1B) MAKING SURE NOT TO ALIGN ONE OF THE SET SCREWS (1E) IN THE COVER WITH THE SLIT IN THE INNER RING (1B).
6. ONCE YOU HAVE DONE THAT, SQUEEZE THE COVER (1D) AND THE INNER RING (1B) TOGETHER AND TIGHTEN THE TWO SET SCREWS (1E) SECURELY. BE CAREFUL NOT TO STRIP THE THREADS.

