

**BIG BIKE PARTS®**

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

# INSTALLATION INSTRUCTIONS

Drive Shaft Cover

V-Star 650

Part No. 63-129

ITEMS REQUIRED: 14 MM WRENCH, 6 MM ALLEN WRENCH

1. LOCATE THE TWO BOLTS THAT HOLD THE GEAR CASE HOUSING COVER. THEY ARE LOCATED WHERE THE DRIVE SHAFT ENTERS THE REAR AXLE ASSEMBLY AND ARE THE TWO BOLTS CLOSEST TO THE FRONT OF THE BIKE.
2. USING THE 14 MM WRENCH, REMOVE THE LOWER BOLT HOLDING THE GEAR CASE HOUSING COVER TO THE FRAME. THE BOLT WILL NO LONGER BE USED.
3. INSERT THE PROVIDED M10 BOLT FIRST THROUGH THE DRIVE SHAFT COVER AND THEN THROUGH THE SPACER AND THEN INTO THE FRAME. START THREADING THE BOLT INTO THE THREADS BUT DO NOT TIGHTEN ALL THE WAY.
4. REMOVE THE UPPER BOLT USING THE 14 MM WRENCH. THIS BOLT WILL NO LONGER BE NEEDED.
5. INSERT THE SECOND M10 BOLT AS IN STEP 3.
6. TIGHTEN BOTH BOLTS TO MANUFACTURES SPECS USING THE 6 MM ALLEN WRENCH.