

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

PART NO. 63-215

SWING ARM COVER  
YAMAHA XVS 950 V-STAR

Copyright © 2009 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

8/24/2010

**TOOLS NEEDED:** TAPE MEASURE SOLVENT (SUCH AS RUBBING ALCOHOL) SHOP CLOTH

**HARDWARE INCLUDED:** (4) 3M DUAL LOCK FASTENERS

## INSTALLATION:

- 1.) USING THE SHOP CLOTH AND THE SOLVENT, CLEAN THE LEFT SIDE SWING ARM COVER TO REMOVE ANY DIRT OR DEBRIS, IN THE AREA SHOWN, AND LET IT DRY.
- 2.) PEEL THE BACKING FROM ONE OF THE 3M DUAL LOCK FASTENERS (A) (SHIPPED LOOSE) AND APPLY TO THE SWING ARM (C), IN THE APPROXIMATE LOCATION SHOWN. REPEAT THIS PROCESS FOR THE SECOND 3M DUAL LOCK FASTENER (A). PRESS FIRMLY FOR PROPER ADHESION OF THE 3M DUAL LOCK FASTENERS (A) TO THE SWING ARM (C).
- 3.) EACH SWING ARM COVER (B) COMES WITH (2) PRE-APPLIED 3M DUAL LOCK FASTENERS. POSITION (1) SWING ARM COVER (B) OVER THE 3M DUAL LOCK FASTENERS (A) ON THE LEFT SWING ARM (C). BE SURE TO LINE THE CONTOUR ON THE SWING ARM COVER (B) WITH THE AXLE BOLT ON THE SWING ARM (C). APPLY PRESSURE TO THE OUTSIDE OF THE SWING ARM COVER (B) SO THAT THE 3M DUAL LOCK FASTENERS (A) LOCK INTO EACH OTHER.
- 4.) REPEAT STEPS 1-3 FOR THE RIGHT SWING ARM COVER INSTALLATION.

