

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 63-304

## CHROME SIDE COVERS ABS YAMAHA V-STAR1300

06/25/07

TOOLS NEEDED: 5MM ALLEN WRENCH 1/4" SOCKET SOCKET WRENCH  
PHILLIPS SCREWDRIVER THREADLOCKER

**NOTE: WE RECOMMEND USING THREADLOCKER ON ALL HARDWARE INSTALLED.**

1. USING A 5MM ALLEN WRENCH, REMOVE THE SCREW HOLDING THE RIGHT SIDE COVER.
2. WITH THE SCREW REMOVED, PUSH THE FRONT OF THE COVER TOWARDS THE FRONT OF THE BIKE UNTIL IT RELEASES FROM THE RUBBER BUSHINGS.
3. INSTALL THE NEW RIGHT SIDE COVER BY SLIDING THE FRONT ONTO THE RUBBER BUSHINGS AND PLACING THE SUPPLIED METAL BUSHING THROUGH THE HOLE IN THE RIGHT SIDE COVER. THE LARGE FLANGE SHOULD BE ON THE OUTER FACE OF THE COVER. INSTALL THE SCREW REMOVED IN STEP 1.
4. USING THE 1/4" SOCKET, SOCKET WRENCH, AND SUPPLIED SECURITY TORX BIT REMOVE THE SCREW FOR THE LEFT SIDE COVER.
5. WITH THE SCREW REMOVED, PUSH THE FRONT OF THE COVER TOWARDS THE FRONT OF THE BIKE UNTIL IT RELEASES FROM THE RUBBER BUSHINGS.
6. USING THE PHILLIPS SCREW DRIVER, REMOVE THE 3 SCREWS HOLDING THE SEAT RELEASE CABLE BRACKET, NOTING THE POSITION OF THE BRACKET.
7. REMOVE THE SEAT RELEASE CABLE FROM THE BRACKET. THIS WILL MAKE IT EASIER TO INSTALL THE SEAT RELEASE CABLE BRACKET TO THE NEW SIDE COVER.
8. INSTALL THE SEAT RELEASE CABLE BRACKET INTO THE NEW SIDE COVER SO THAT IT IS ORIENTATED THE SAME AS IN THE OEM SIDE COVER. REINSTALL THE CABLE TO THE BRACKET.
9. INSTALL THE NEW LEFT SIDE COVER BY SLIDING THE FRONT ONTO THE RUBBER BUSHINGS AND PLACING THE SUPPLIED METAL BUSHING THROUGH THE HOLE IN THE LEFT SIDE COVER. THE LARGE FLANGE SHOULD BE ON THE OUTER FACE OF THE COVER. INSTALL THE SCREW REMOVED IN STEP 4.