

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 63-316 & 63-317

RADIATOR GRILLE
YAMAHA VSTAR 1300

09/04/07

ITEMS NEEDED: 4MM ALLEN WRENCH 5MM ALLEN WRENCH THREADLOCKER

NOTE: WE RECOMMEND USING THREADLOCKER ON ALL HARDWARE INSTALLED.

INSTALLATION:

1. USING THE 5MM ALLEN WRENCH REMOVE THE SOCKET HEAD CAP SCREWS (A) FROM BOTH THE LOWER RIGHT AND LEFT SIDES OF THE BIKE ATTACHING THE RADIATOR (B) TO THE FRAME (C).
2. SWING THE BOTTOM OF THE RADIATOR (B) OUT, THEN USING THE 4MM ALLEN WRENCH REMOVE THE BUTTON SOCKET HEAD CAP SCREWS ATTACHING EACH SIDE OF THE OEM RADIATOR COVER TO THE RADIATOR (B).
3. REATTACH THE RADIATOR (B) BACK TO THE FRAME (C) USING THE SOCKET HEAD SCREWS (A) REMOVED IN STEP ONE.
4. WITH THE 4MM ALLEN WRENCH REMOVE THE TWO BUTTON SOCKET HEAD CAP SCREWS FROM THE TOP OF THE OEM RADIATOR COVER AND REMOVE THE RADIATOR COVER BY SWINGING THE TOP OF THE COVER OUT AND THEN PUSHING DOWN.
5. REMOVE THE GROMMET (D) FROM THE BOTTOM OF THE OEM RADIATOR COVER AND INSTALL IT INTO THE BOTTOM OF THE NEW RADIATOR COVER (E).
6. PLACE ONE OF THE PROVIDED BUTTON SOCKET HEAD CAP SCREWS (F) THRU EACH OF THE HOLES AT THE TOP OF THE RADIATOR COVER (E) AND SLIDE A SPACER (G) OVER THE SCREW (F) ON THE BACK SIDE OF THE COVER (E).
7. WITH THE COVER (E) TILTED FORWARD SLIGHTLY SO THE SPACERS (G) DON'T FALL OFF THE SCREWS (F), SLIDE THE GROMMETED HOLE OVER THE NIPPLE AT THE BOTTOM OF THE RADIATOR (B). TILT THE RADIATOR COVER (E) BACK AND WITH THE 4MM ALLEN WRENCH TIGHTEN THE BUTTON SOCKET HEAD CAP SCREWS (F) INTO THE THREADED BOSSES ON THE RADIATOR (B).

