

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 63-318

FRONT FENDER RAIL  
YAMAHA V STAR 1300

04/29/08

ITEMS NEEDED: 12MM WRENCH      THREADLOCKER

**NOTE: WE RECOMMEND USING THREADLOCKER ON ALL HARDWARE INSTALLED.**

1. REMOVE ALL FOUR FLANGE HEX HEAD BOLTS HOLDING THE FRONT FENDER TO THE FORKS USING A 12MM WRENCH. BE CAREFUL NOT SCRATCH THE FRONT FENDER ONCE IT IS FREE. TO PREVENT SCRATCHING, HAVE ANOTHER PERSON HOLD THE FRONT FENDER WHILE IT IS LOOSE.
2. INSTALL THE FENDER RAIL REUSING THE OEM BOLTS. THE FENDER RAIL BRACKETS SHOULD BE ON THE INSIDE OF THE FRONT FENDER. MAKE SURE THAT THE REFLECTOR BRACKETS ARE BETWEEN THE FENDER RAIL AND THE FRONT FENDER.
3. TIGHTEN DOWN ALL FOUR BOLTS USING A 12MM WRENCH.