

# BIG BIKE PARTS®

Copyright© 2003 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

# INSTALLATION INSTRUCTIONS

CHROME NECK COVERS

YAMAHA

PART NO. 63-604

XVS 1100

TOOLS NEEDED: 5MM ALLEN WRENCH

10MM WRENCH

12MM WRENCH

INSTALLATION:

1. USING 10MM WRENCH REMOVE THE REAR PILLOW SEAT AND THE RIDERS SEAT.
2. USING 12MM WRENCH REMOVE THE BOLT AT THE BOTTOM OF THE TANK. SLIDE THE TANK BACK FAR ENOUGH TO REMOVE THE FRONT TANK MOUNT RUBBERS OFF THE MOUNTS UNDER THE TANK. (HAVE SOMEONE HOLD TANK SO IT DOESN'T FALL OFF.)
3. USING 10MM WRENCH REMOVE THE SCREWS ON THE FRONT OF EACH OEM NECK COVER.
4. REMOVE BOTH OEM NECK COVERS AND INSTALL NEW CHROME NECK COVERS USING THE NEW SOCKET HEAD BOLT AND WASHERS PROVIDED. TIGHTEN WITH 5MM ALLEN WRENCH.
5. RE-ASSEMBLE BY REVERSING STEPS 1 & 2.