

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

Front Fender Rail

Fits Kawasaki

Part No. 71-122

VN2000

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

TOOLS NEEDED: 6MM ALLEN WRENCH 13MM COMBINATION WRENCH

INSTALLATION:

1. ONLY INSTALL ONE SIDE AT A TIME. START ON THE RIGHT SIDE OF THE FRONT FENDER, REMOVE THE TWO OEM BOLTS HOLDING THE FRONT FENDER ON THE FORKS. THESE BOLTS ARE NO LONGER NEEDED.
2. TAKE THE FENDER RAIL AND SLIDE IT UP UNDERNEATH THE FENDER UNTIL THE RIGHT SIDE MOUNTING HOLES ARE LINED UP WITH THE FENDER AND FORK MOUNTING HOLES.
3. USING THE SUPPLIED HARDWARE, TAKE 2 OF THE BOLTS AND BOLT THE FORK BACK TO THE FENDER, THE BOLTS WILL THREAD THROUGH THE NUTS ON THE FENDER AND STICK THROUGH THE MOUNTING HOLES ON THE FENDER RAIL. TIGHTEN THE BOLT COMPLETELY SO THAT THE THREADED PORTION IS STICKING THROUGH THE MOUNTING HOLES ON THE FENDER RAIL.
4. USING THE SUPPLIED NUTS, THREAD ONE ON EACH BOLT TO FASTEN DOWN THE FENDER RAIL, TIGHTEN USING A 13MM COMBINATION WRENCH.
5. REPEAT STEPS 1-4 FOR LEFT SIDE.