

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 71-124

CURVED CAST SOLO RACK
KAWASAKI VN2000

TOOLS NEEDED: IGNITION KEY 2MM ALLEN WRENCH 2.5MM ALLEN WRENCH, 4MM ALLEN WRENCH
PLIERS 8MM SOCKET WRENCH 10MM SOCKET WRENCH

1. USING THE IGNITION KEY REMOVE THE RIGHT SIDE COVER.
2. PULL THE RELEASE CABLE LOOP, LOCATED BEHIND RIGHT SIDE COVER, TO RELEASE THE LATCH FOR THE PILLOW SEAT. WHILE PULLING THE RELEASE CABLE LIFT UP ON THE FRONT OF THE PILLOW SEAT AND PULL FORWARD REMOVING THE PILLOW SEAT.
3. WITH AN 8MM SOCKET WRENCH REMOVE THE TWO SCREWS WHICH ATTACH THE DRIVER SEAT TO THE REAR FENDER.
4. WITH A PLIERS COME UP FROM THE BOTTOM OF THE FENDER AND PINCH THE PLASTIC CABLE RETAINER TOGETHER WHICH HOLDS THE RELEASE CABLE TO THE FENDER AND PULL IT OUT OF THE FENDER. DETACH RELEASE CABLE FROM THE MOUNTING BRACKET LOCATED BEHIND THE RIGHT SIDE COVER. WITH A 10MM SOCKET WRENCH REMOVE BOTH MOUNTING BRACKETS AND RELEASE CABLE FROM THE REAR FENDER.
5. ATTACH THE FRONT MOUNTING BRACKETS PROVIDED TO THE SOLO RACK INTO THE CORRESPONDING MOUNTING SLOTS AND SECURE USING A 2MM ALLEN WRENCH AND THE PROVIDED THE SET SCREWS. THEN USING A 2.5MM ALLEN WRENCH, ATTACH THE REAR MOUNTING BRACKET TO THE SOLO RACK WITH THE M4 SCREWS.

NOTE: IF YOU ARE NOT USING A TUX TAIL, THE RUBBER PAD WILL NEED TO BE ATTACHED TO THE BOTTOM OF THE REAR MOUNTING BRACKET.

6. ALIGN THE FRONT SOLO RACK BRACKETS ON TOP OF THE DRIVER SEAT MOUNTING TABS AND ATTACH USING A 4MM ALLEN WRENCH AND TWO OF THE M6 SCREWS. THEN ATTACH THE REAR SOLO RACK MOUNTING BRACKETS USING THE 4MM ALLEN WRENCH USING THE OTHER TWO M6 SCREWS.
7. REATTACH THE RIGHT SIDE COVER IN REVERSE ORDER AS STEP #1.

