

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright © 2006 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 71-132

FRONT LEFT CALIPER COVER
KAWASAKI VN2000/VN900

TOOLS NEEDED:

12MM WRENCH

5MM ALLEN WRENCH

1. WITH A 12MM WRENCH REMOVE BOTH OEM HEX FLANGE HEAD SCREWS WHICH ATTACH THE LEFT BRAKE CALIPER TO THE MOUNTING BRACKET.
2. INSERT ONE M8 (M10 VN900) BUTTON SOCKET HEAD CAP SCREW THRU THE TOP HOLE IN THE CALIPER COVER, PLACING ONE SPACER OVER THE SCREW ON THE BACKSIDE OF THE COVER.
3. PLACE STEPPED LEFT FRONT CALIPER COVER OVER THE BRAKE CALIPER, ALIGNING THE M8 (M10 VN900) SCREW WITH THE TOP HOLES IN THE MOUNTING BRACKET AND CALIPER, THEN HAND THREAD THE SCREW INTO CALIPER ENOUGH SO IT WON'T FALL OUT.
4. PLACE THE OTHER SPACER BEHIND THE BOTTOM CALIPER COVER SLOT, INSTALL THE OTHER PROVIDED BUTTON SOCKET HEAD CAP SCREW THRU THE SLOT, ALIGNING THE BOLT WITH MOUNTING BRACKET AND CALIPER, THEN START THE SCREW BY HAND.
5. TIGHTEN BOLTS DOWN TO MANUFACTURER SPECIFICATIONS WITH A 5MM ALLEN WRENCH.