

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 71-311

ABS CHROME SIDE COVERS
KAWASAKI VN900

TOOLS NEEDED: PHILLIPS SCREWDRIVER

1. REMOVE THE SEAT FROM THE BIKE BY INSERTING THE KEY INTO THE LOCK LOCATED IN THE LEFT SIDE COVER AND TURN KEY TO THE RIGHT.
2. USING THE PHILLIPS SCREWDRIVER REMOVE THE SCREW FROM THE TOP OF THE LEFT SIDE COVER. REMOVE THE LEFT SIDE COVER AND INSTALL THE NEW SIDE COVER REUSING THE SCREW. (NOTE: REMOVE THE WELLNUT FROM THE OEM SIDE COVER AND INSTALL IT IN THE NEW SIDE COVER BEFORE INSTALLING ON THE BIKE).
3. USING THE PHILLIPS SCREWDRIVER REMOVE THE SCREW FROM THE TOP OF THE RIGHT SIDE COVER AND REMOVE THE RIGHT SIDE COVER. THE LOWER PANEL WILL ALSO NEED TO BE REMOVED AT THE SAME TIME BECAUSE THEY ARE ATTACHED.
4. REMOVE THE THREE SCREWS THAT ATTACH THE LOWER PANEL TO THE SIDE COVER AND REMOVE THE LOWER PANEL. THEN REUSING THE THREE SCREWS ATTACH THE LOWER PANEL TO THE NEW SIDE COVER.
5. INSTALL THE NEW SIDE COVER AND LOWER PANEL REUSING THE SCREW REMOVED IN STEP 3.
6. REINSTALL THE SEAT ON THE BIKE.