

BIG BIKE PARTS

Copyright © 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

INSTALLATION INSTRUCTIONS

HALOGEN SPOT LIGHT KIT

PART NO. 1-231

PART NO. 1-232

PART NO. 1-235

PART NO. 71-104

PART NO. 81-101

TYPICAL INSTALLATION

HONDA VT600

HONDA VT1100 ACE

HONDA VT1100

KAWASAKI VN800/1500

SUZUKI VZ800

ITEMS REQUIRED: 14MM WRENCH (MM SIZE WILL VARY TO MATCH YOUR MOTORCYCLE FORK BOLT SIZE)
WIRE CRIMPER
DRILL & 13/16" DRILL BIT

- THIS SPOTLIGHT MOUNTING BRACKET IS DESIGNED TO MOUNT TO THE TOP OF YOUR FORK BRACE AND UNDERNEATH THE HEADLIGHT MOUNT BRACKET.
- REMOVE THE BOLTS THAT HOLD THE HEADLIGHT TO THE FORK AND INSERT THE SPOTLIGHT BRACKET AND REINSTALL THE BOLTS.
- USING A 14MM WRENCH, INSTALL THE SPOTLIGHT TO THE BRACKET (1A). POSITION AND TIGHTEN.
- REMOVE THE BULLET CONNECTORS FROM THE TWO BLACK WIRE LEADS AND SOLDER CONNECT THEM TO THE WIRE LEADS ON THE SPOT LIGHTS.
- LOCATE YOUR BIKES BATTERY, FUSE BLOCK AND/OR ACCESSORY TERMINALS AND WIRE ACCORDING TO THE SCHEMATIC BELOW.
 - WIRE SMALL GREEN & RED HARNESS WITH INLINE FUSE DIRECTLY TO BATTERY RED (+) POSITIVE, GREEN (-) NEGATIVE.
 - FIND A CONVENIENT LOCATION FOR SWITCH AND DRILL A PILOT HOLE FIRST, THEN DRILL A 13/16" HOLE FOR SWITCH.
 - ROUTE WIRE HARNESS AND PLUG THREE SPADE CONNECTORS TO SWITCH PER DIAGRAM; (GREEN = GROUND; ORANGE = SUPPLY; BLUE = LEAD).
 - PLUG THE GREEN AND ORANGE LEADS WITH BULLET CONNECTORS FROM SWITCH TO THE BIKE'S ACCESSORY TERMINAL, FUSE BLOCK OR OTHER SOURCE.
 - CONNECT THE REMAINING FIVE LEADS (2 BLACK, 1 RED, 1 GREEN, 1 BLUE) TO THE RELAY PROVIDED.
- TEST LIGHTS FOR PROPER OPERATION BEFORE REINSTALLING ANY REMOVED SIDE COVERS, SEATS, ETC. SECURE RELAY TO KEEP FROM BOUNCING.

