

# BIG BIKE PARTS®

## INSTALLATION INSTRUCTIONS

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

PART # 81-109

CHROME SIDE COVERS

SUZUKI VZ1600 / M95 04-05

KAWASAKI VN1600B 04-05 VN1500P 02-03

Revised 8-11-05

TOOLS NEEDED: PHILLIPS SCREWDRIVER  
CRESCENT WRENCH  
5MM WRENCH

### INSTALLATION:

1. USING PHILLIPS SCREWDRIVER, REMOVE SCREW FROM RIGHT SIDE COVER.
2. REMOVE THE RIGHT SIDE COVER AND INSTALL THE NEW COVER USING ALLEN HEAD SCREW PROVIDED.
3. USE KEY TO TAKE LEFT SIDE COVER OFF.
4. REMOVE THE RUBBER GROMMETS ON THE OEM COVER AND INSTALL ON THE NEW CHROME COVER.
5. USE CRESCENT WRENCH TO REMOVE NUT ON THE BACKSIDE OF KEY TUMBLER AND REMOVE IT. INSTALL KEY TUMBLER ON NEW CHROME COVER.