

# **BIG BIKE PARTS®** INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 82-230

CHROME DRIVESHAFT COVER  
SUZUKI VL800 C50 & M50

08/30/07

1. USING A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED WITH A CLEAN, LINT-FREE RAG CLEAN THE DRIVE SHAFT HOUSING.
2. STICK THE LOOSE PIECE OF DUAL LOCK TO THE PIECE ATTACHED TO THE BACK OF THE DRIVE SHAFT COVER, MAKING SURE THAT THE TWO PIECES ARE FULLY ENGAGED WITH EACH OTHER.
3. PLACE THE DRIVE SHAFT COVER OVER THE DRIVE SHAFT HOUSING AND ORIENT IT TO YOUR LIKING, NOTE THE PLACEMENT OF THE COVER DURING THE DRY RUN.
4. PEEL THE ADHESIVE BACKING OFF THE DUAL LOCK AND PLACE THE DRIVE SHAFT COVER OVER THE DRIVE SHAFT HOUSING. PRESS DOWN FIRMLY AND CONTINUE TO APPLY PRESSURE FOR A COUPLE MINUTES TO ASSURE THAT THE PART IS FULLY ADHERED.