

Revised 7/25/2017

ITEMS REQUIRED: SMALL STRAIGHT BLADE SCREWDRIVER  
5MM, 6MM ALLEN WRENCH  
1/4" DRILL BIT AND ELECTRIC DRILL

#3 PHILLIPS SCREWDRIVER  
8MM, 10MM WRENCH  
CENTER PUNCH & HAMMER

1. USING STRAIGHT BLADE SCREWDRIVER, PRY OFF THE TWO FORK COVER CAPS AND WITH A 5MM ALLEN WRENCH UNFASTEN THE TWO BOLTS (1A). REMOVE THE FORK COVER.
2. PUL OUTWARD AND FORWARD TO REMOVE THE L/R FENDER SIDE COVERS. (1B)
3. USING 8MM AND 10MM WRENCHES, REMOVE THE 3 BOLTS FROM THE L/H DISC COVER. REPEAT FOR THE R/H DISC COVER. (NOTE FOR RE-INSTALLATION: THE TOP 10MM BOLTS (1C) DO NOT HAVE COLLARS INCLUDED.)
4. USING THE PHILLIPS SCREWDRIVER, UNFASTEN SPEEDOMETER CABLE (1D).
5. USING THE 8MM WRENCH, REMOVE THE L/R SIDE FENDER BOLTS (1E).
6. USING THE 6MM ALLEN WRENCH, REMOVE THE FOUR TOP BOLTS (1F) FROM THE FORK STAY BRACKET AND REMOVE THE BRACKET.
7. WITH THE REAR FENDER OFF THE MOTORCYCLE, HOLD THE NEW FENDER EXTENDER IN PLACE AND USING A CENTER PUNCH (2A) AND HAMMER, LIGHTLY TAP THE THREE DRILLING LOCATIONS. SET THE FENDER EXTENDER ASIDE AND DRILL THREE 1/4" HOLES AT MARKED LOCATIONS. (2B)
8. FASTEN THE FENDER EXTENDER TO THE FENDER WITH SPECIAL HARDWARE PROVIDED (3A) MAKING SURE (3B) IS ON THE INSIDE IN THE RECESS OF THE EXTENSION PROVIDED.
9. RE-INSTALL ALL ITEMS PREVIOUSLY REMOVED IN STEP 1.

