

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 2-452L, 2-452T

ROTOR ACCENTS
HONDA GL1500/6 GOLDWING

Revised 12-19-07

ITEMS REQUIRED: 8MM WRENCH 9/64" DRILL BIT DUCT TAPE
 10MM WRENCH 11/64" DRILL BIT

INSTALLATION:

1. SET YOUR BIKE ON ITS CENTER STAND FOR SAFETY.
2. PULL FORWARD AND OUTWARD TO REMOVE THE L/R FENDER SIDE COVER (1A).
3. USING A 8MM WRENCH, REMOVE THE TWO BOLTS (1B) FROM L/R ROTOR COVERS, BE CAREFUL NOT TO LOSE THE COLLARS.
4. USING A 10MM WRENCH, REMOVE THE UPPER BOLT (1C) ON L/R ROTOR COVERS, REMOVE L/R ROTOR COVERS.
5. USE A MILD SOAP WITH WATER TO CLEAN THE INSIDE EDGE OF THE ROTOR ACCENTS, WIPING DRY WITH A CLEAN NON-ABRASIVE CLOTH.
6. FASTEN THE LIGHT STRIP PROVIDED ALONG THE INNER EDGE OF THE ROTOR ACCENTS. THE WIRES FOR THE LED STRIP SHOULD END AT THE BOTTOM.

NOTE: FOR 2-452T THE AMBER POINT OUTWARD AND THE RED AND BLUE POINT INWARD.

7. LAY THE ROTOR COVER ON A CLEAN FLAT SURFACE AND POSITION THE ROTOR ACCENT OVER THE ROTOR COVER. LEAVE SUFFICIENT ROOM AT THE BOTTOM END OF THE RING AND ROTOR LIGHT TO ALLOW ROUTING THE WIRES THROUGH THE ROTOR COVER.
8. USING A 9/64" DRILL BIT, FIRMLY HOLD THE TRIM RING IN POSITION AND START AT THE UPPER MOST MOUNTING HOLE, DRILL YOUR FIRST HOLE. BEFORE DRILLING THE OTHER HOLES SECURE THE TRIM RING WITH ONE BOLT, SMALL AND LARGE WASHER AND A NYLOCK NUT.
9. TO INSURE A TIGHT FIT BETWEEN THE TRIM RING AND ROTOR COVER, STRETCH THE RING AROUND THE COVER DRILLING ONE HOLE AT A TIME AND SECURING WITH THE BOLT, WASHERS AND NYLOCK NUT. REPEAT STEPS 8 & 9 FOR THE OTHER SIDE.
10. USING A CLEAN SOFT CLOTH, COVER YOUR WORK SURFACE AND FLIP YOUR ROTOR COVER OVER. NEAR THE BOTTOM AT THE END OF THE ROTOR LIGHT, DRILL A 11/64" HOLE TO ROUTE THE WIRES THROUGH THE ROTOR COVER. ROUTE THE WIRE UP THE ROTOR COVER TO EXIT AT THE REAR OF THE FORKS. USE DUCT TAPE TO SECURE THE WIRES ON THE INSIDE OF THE ROTOR COVER, POSITIONING THE WIRES CLEAR AND AWAY OF MOVING PARTS.
11. REMOUNT YOUR L/R SIDE ROTOR COVERS AND CONNECT THE WIRES TO OUR ACCESSORY SWITCH OR KEYED POWER; WHICH EVER YOU PREFER.
12. REINSTALL L/R FENDER SIDE COVERS.

