

# BIG BIKE PARTS®

Copyright© 2005 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.

## INSTALLATION INSTRUCTIONS

LED CLEAR TURN SIGNAL  
PART NO. 52-743 & 52-754

FITS GL1800  
GOLDWING

Revised 08-14-06

TOOLS NEEDED: PHILLIPS SCREWDRIVER  
T15 TORX SCREWDRIVER

INSTALLATION:

**NOTE: AS LED TURN SIGNALS DRAW AMPERAGE DIFFERENTLY THAN INCANDESCENT, YOU WILL NEED TO INSTALL A LOAD EQUALIZER TO MAKE THESE TURN SIGNALS OPERATE PROPERLY. WE RECOMMEND OUR BBP # 13-304 DUAL LOAD EQUALIZER.**

1. RECOMMEND PUTTING BIKE ON ITS CENTER STAND.
2. USING PHILLIPS SCREWDRIVER, REMOVE THE PHILLIPS SCREW ON BOTTOM OF MIRROR HOUSING AND REMOVE THE MIRROR.
3. USING T15 TORX SCREWDRIVER REMOVE THE THREE TORX SCREWS HOLDING THE MIRROR FRAME TO MIRROR HOUSING.
4. REMOVE THE BLACK PLASTIC COVER ON THE INSIDE OF THE MIRROR AT THE HINGE TO THE BIKE. THIS WILL ALLOW ACCESS TO REMOVE THE OEM BULB SOCKET HARNESS.
5. REMOVE THE BULB SOCKET HARNESS BY DISCONNECTING THE 3-PIN CONNECTOR FROM THE BIKES HARNESS.
6. REMOVE THE OEM LIGHT HOUSING FROM MIRROR HOUSING AND REPLACE WITH NEW LED LIGHT HOUSING. CONNECT THE NEW MALE 3-PIN CONNECTOR FROM THE LED TO THE 3-PIN CONNECTOR ON THE BIKE HARNESS.
7. REASSEMBLE ALL COMPONENTS IN THE REVERSE ORDER.

THE TURN SIGNALS WILL FLASH FASTER WITHOUT A LOAD EQUALIZER INSTALLED.