

Copyright © 2019 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-950

PASSENGER BACKREST

FITMENT: HONDA GOLDWING 2018-NEWER

4/4/2019

TOOLS NEEDED: 5MM ALLEN WRENCH

6MM ALLEN WRENCH

HACKSAW





PHILLIPS SCREWDRIVER




13MM WRENCH

**PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING. \*USE REMOVABLE THREAD LOCK ON ALL FASTENERS\***  
**ESTIMATED INSTALLATION TIME: 30 TO 45 MIN.**

**INSTALLATION:**

1. OPEN BOTH SADDLEBAGS AND REMOVE THE SIDE COVER FROM EACH SIDE OF THE BIKE (FIG. 1).
2. USE A 6MM ALLEN WRENCH TO REMOVE THE TWO SEAT BOLTS (FIG. 2 SHOWS LEFT SIDE).
3. UNPLUG THE SEAT HARNESS CONNECTOR ON THE RIGHT SIDE OF THE BIKE (FIG. 3) AND REMOVE THE SEAT BY LIFTING THE FRONT OF THE SEAT AND PULLING FORWARD TOWARDS THE FRONT OF THE BIKE.
4. REMOVE THE REAR COVER FILLERS BY PULLING STRAIGHT UP ON EACH (FIG. 4).
5. USE A 5MM ALLEN WRENCH TO REMOVE THE TWO SCREWS HOLDING THE REAR COVER (FIG. 5).
6. USING THE POINT ON A PHILLIPS SCREW DRIVER PUSH IN THE CENTER OF THE TWO PLASTIC PUSH PINS SHOWN IN FIG. 5 AND REMOVE THEM.  
**NOTE: AFTER REMOVING ALL PLASTIC PUSH PINS, PUSH THE CENTER BACK TO RESET THEM FOR INSTALLATION.**
7. REMOVE THE REAR COVER BY CAREFULLY PULLING STRAIGHT BACK TO RELEASE-FIG. 6 SHOWS THE TABS HOLDING THE COVER ON FOR REFERENCE.
8. TURN THE REAR COVER OVER AND USE A PHILLIPS SCREWDRIVER TO REMOVE THE FOUR SCREWS SHOWN IN FIG. 6.
9. CAREFULLY PULL EACH END OF THE FILLER TOWARDS THE CENTER TO RELEASE FROM THE REAR COVER (FIG. 6).
10. THE BOTTOM OF THE FILLER PIECE HAS TWO FACTORY LINES SHOWN IN FIG. 7. CUT ON THE INSIDE OF EACH LINE AND REMOVE THE CENTER OF THE FILLER (FIG. 7). (CENTER WILL NOT BE REUSED)
11. REINSTALL THE OUTER FILLER PIECES ON THE REAR COVER.
12. INSTALL THE PASSENGER BACKREST USING THE THREE 8MM BOLTS AND WASHERS SUPPLIED ACCORDING TO FIG. 8.
13. REPEAT STEPS 1 THROUGH 7 IN REVERSE ORDER.





**WARNING**

BACKREST IS DESIGNED TO SUPPORT RIDERS LOWER BACK WHEN RIDING. DO NOT APPLY EXCESSIVE FORCE BY PUSHING BACK WITH YOUR FULL BODY WEIGHT. DO NOT USE BACKREST TO LIFT OR SUPPORT MOTORCYCLE.

**NOTICE**

IGNORING THE CONTENTS OF THESE INSTRUCTIONS MAY AFFECT THE PRODUCT PERFORMANCE AND FUNCTIONALITY. NOT FOLLOWING THESE INSTRUCTION MAY CAUSE DAMAGE TO THE PRODUCT OR THE VEHICLE TO WHICH IT IS BEING ATTACHED.

